

Miles from Junction Switch Cayuga Sub.	Yard Limits	Switching Zones	CANAL SUBDIVISION		Office Signals	Siding Capacity in Feet	
			STATIONS				
0.0			CTC	FEEDER WEST.....PY	F W		
				Jct. with Cayuga Sub.			
0.8				0.8			
				FEEDER SOUTH.....P			
				2.2			
				DAIN.....*B			
3.0			0.7				
			TUNNEL BRIDGE SOUTH...P				
3.7			0.3				
			TUNNEL BRIDGE NORTH...P				
4.0			0.9				
			WELLAND DIAMOND.....P				
4.9			1.2				
			WELLAND.....PZ		Yard		
6.1	5.0 8.0		8.1				
			THOROLD.....Y				
14.2			Jct. with Thorold Sub.				
<p>CTC between Feeder West and mileage 5.0 controlled by Train Dispatcher NI London. Rules 321-323 applicable between mileage 8.0 and Thorold. Section 14 Form 835 not applicable</p>							

CANAL SUBDIVISION FOOTNOTES

- 1 RULE MODIFICATIONS**
 - 1.1 CLEARANCES**
All movements between Feeder West and mileage 5.0 must be authorized by a clearance OK'd by Train Dispatcher NI London except movements which originate at Dain and movements which originate from the C.R.
 - 1.2 TRAIN REGISTER MODIFICATIONS**
DAIN-*Bulletins only.
 - 1.3 CTC SPECIAL FEATURES**
No train or engine shall clear the main track at the following switch mileage 4.2 (Hydro Spur).
 - 1.4 SPECIAL INSTRUCTIONS APPLY**
SYSTEM 2.0—applies between mileage 8.0 and Thorold.
 - 1.5 OTHER MODIFICATIONS**
RULE 14(m) paragraph one—not applicable.
RULES 294 to 300—as shown on pages 186 and 187 are in effect between mileage 0.0 and mileage 5.0.
- 2 INTERLOCKINGS**
 - 2.1 Railway crossing at grade**
Consolidated Rail Corp. mileage 4.9 controlled.
Train Dispatcher NI London controls all movements. Rules 264 and 672 are applicable.
Southward movements must not exceed 15 miles per hour between approach Signal 54 and interlocking Signal 48. Signal 54 is located to the left of track at mileage 5.4. Movements on service track must not exceed 10 miles per hour in either direction through interlocking. (R-16955).
- 3 EQUIPMENT RESTRICTIONS**
 - 3.1** Cars exceeding 263,000 lbs. gross must be covered by handling instructions.

4 SPEEDS		Miles Per Hour
		All Trains
4.1	Mileage	
	0.0 to 8.0 zone	30
	4.9 Interlocking C.R. Corp.	30
	8.0 to 14.2 zone	50
	13.9 to 14.2	15

5 PUBLIC CROSSINGS AT GRADE

- 5.1 Mileage 2.8** (Regional Road 68)—Item 1.21 Form 696 applies. Crossing circuit sign is in place 1200 feet south of crossing. Northward movements stopping south of crossing to perform switching must leave leading car south of the sign. Engine must be south of sign before again proceeding towards crossing.
- 5.2 Mileage 4.0** (Regional Rd. 33)—automatically protected. Northward movements complying with Rule 264 must be protected by a member of the crew.
- 5.3 Mileage 4.8** (Ontario St.)—Item 1.21 Form 696 applies on other than main track and service track. Stop sign each side of crossing.
- 5.4 Mileage 5.5** (Lincoln St.)—Item 1.21 Form 696 applies. Cars must not be left standing closer than 200 feet from crossing.
- 5.5 Mileage 5.7** (Hagar St.)—Cars must not be left standing closer than 100 feet from crossing.
- 5.6 Mileage 6.1** (East Main Street) Item 1.21 Form 696 applies. "Stop" signs located each side of crossing west of service track govern movements on both the main track and service track. Cars must not be left within 50 feet of "Stop" signs. Pushbuttons located north of main track are for movements on yard tracks only.

6 SPURS AND OTHER TRACKS

- 6.1 CONNECTING TRACK**
Mileage 0.8—Extends northward 0.5 miles connecting to south track of Cayuga Sub. at mileage 20.1.
CTC controlled by Train Dispatcher NI London.
MAXIMUM SPEED 15 miles per hour
- 6.2 DAIN**
Mileage 3.6—Extend southward 1.1 miles.
PUBLIC CROSSINGS AT GRADE
Mileage 0.6 (Regional Rd. No. 23)—Stop signs at each side of crossing. Movements must be protected by a member of the crew.
- 6.3 SERVICE TRACK**
Extends from mileage 4.0 to mileage 7.7.
MAXIMUM SPEED 10 miles per hour
PUBLIC CROSSINGS AT GRADE
Mileage 4.8 (Ontario St.)—automatically protected. Northward movements when complying with Rule 264 must be protected by a member of the crew.
Mileage 5.5 (Lincoln St.) } Item 1.21 Form 696 applies.
Mileage 5.7 (Hagar St.) }
Mileage 6.1 (East Main St.)—Item 1.21 Form 696 applies. Stop signs located on each side of crossing. Cars must not be left within 100 feet of crossing. Pushbuttons located each side of crossing are for movement from or to other than main track and service track.
- 6.4 CONNECTING TRACK**
Mileage 13.7—Extends eastward 0.3 miles connecting to Thorold Sub. at mileage 4.1.
MAXIMUM SPEED 15 miles per hour