

WESTWARD TRAINS		Miles from Endako	Yard Limits	TELKWA SUBDIVISION			Office Signals	Siding Capacity in Feet	EASTWARD TRAINS			
FIRST CLASS				FIRST CLASS		FOURTH CLASS						
---	9			10	---	720			876	878		
---	Passenger	Passenger	---	Freight	Freight	Freight						
---	Sun., Wed., Fri.	---	---	---	---	---						
				STATIONS								
---	0240	0.0	↓ 1.3	ENDAKO --- KPWYZ	KO	5160	s0330	---	0500	1340	1910	
---	0248	6.2	---	6.2 SAVORY	---	2280	0317	---	0448	1325	1858	
---	0305	14.8	---	8.6 PRIESTLY	---	2130	0305	---	0436	1313	1846	
---	0313	20.8	---	6.0 SHERATON	---	2480	0256	---	0428	1304	1838	
---	0320	27.1	---	6.3 TINTAGEL	---	2460	0248	---	0419	1255	1829	
s0333	35.0	33.7	↓	7.9 BURNS LAKE --- PWZ	BK	2430	s0235	---	0405	1241	1815	
---	0340	40.3	36.7	5.3 DECKER LAKE	---	---	0221	---	---	---	---	
---	0346	45.3	---	5.0 PALLING	---	6010	0215	---	0346	1226	1800	
---	0353	51.3	---	6.0 ROSE LAKE	---	3040	0208	---	0320	1216	1753	
---	0403	58.9	---	7.6 FORESTDALE	---	2460	0158	---	0307	1203	1741	
---	0412	66.6	---	7.7 TOPLEY	---	6080	0149	---	0255	1151	1729	
---	0419	72.9	---	6.3 PEROW	---	2550	0142	---	0246	1142	1720	
---	0427	80.1	---	7.2 KNOCKHOLT	---	2290	0134	---	0236	1132	1710	
s0435	85.1	83.9	↓	5.0 HOUSTON --- PZ	HU	2430	s0128	---	0229	1125	1703	
---	0440	87.5	86.0	2.4 DEREK	---	4650	0123	---	0225	1120	1700	
---	0446	88.4	---	3.9 BARRETT	Y	6120	0116	---	0219	1114	1654	
---	0456	91.4	---	7.4 WALCOTT	---	2430	0107	---	0209	1104	1644	
---	0508	98.8	---	8.3 QUICK	---	2460	0055	---	0156	1050	1630	
---	0515	107.1	---	5.7 HUBERT	---	2540	0048	---	0146	1042	1622	
F0520	116.0	---	---	3.2 TELKWA --- P	A	1010	F0042	---	0140	1036	1616	
---	0528	119.4	---	3.4 TATLOW	---	2390	0037	---	0130	1030	1610	
s0540	125.2	121.0	↑	5.8 SMITHERS --- CKPWYZ	WA	4280	0030	---	0120	1020	1600	
---							Tues., Thurs., Sat.	---	Daily	Daily	Daily	
---	9						10	---	720	876	878	

TELKWA SUBDIVISION FOOTNOTES

1 RULE MODIFICATIONS

1.1 **RULE 5—Endako**—the time of eastward regular trains except first class trains applies at the yard west switch.

2 GENERAL FOOTNOTES

- 2.1 **Endako**—Siding is located between east and west switches.
- 2.2 **Houston**—Eastward one mile to yard limit sign (mileage 87.0) is located on north side of main track.
- 2.3 **Smithers**—Siding is located between Shop west lead and yard east lead. Siding switches designated by letter "S" stencilled on switch target.

3 EQUIPMENT RESTRICTIONS

- 3.1 Units in series 4000-4017, 5000-5299 prohibited.
- 3.2 Cars exceeding 263,000 lbs. gross must be covered by handling instructions.

4 SPEEDS

4.1 Mileage	Zone	Miles per Hour	
		Passenger	Freight
0.0 to 125.2		50	40
0.8 to 1.0	-----	10	10
2.3 to 2.4	-----	10	10
7.8 to 8.3	-----	40	35
27.7 to 28.2	-----	40	35
30.8 to 33.6	-----	35	30
53.0 to 54.5	-----	40	35
66.5 to 66.9	-----	10	10
99.3 to 99.7	-----	45	--
102.1 to 104.1	-----	35	30
111.6 to 111.9	-----	40	35
119.7 to 120.0	-----	45	--
4.2 Sidings and Other tracks	-----	10	10

CONDITIONAL SPEEDS

- 4.3 **Mileage 34.8 (Francois Drive)**
 Westward movements approaching within 1400 feet of crossing and until crossing occupied ----- 35 35
 Eastward movements approaching within 1400 feet of crossing and until crossing occupied ----- 40 --
 Eastward movements proceeding at less than 10 miles per hour within 1400 feet of crossing and until crossing occupied ----- 10 10
- 4.4 **Mileage 85.2 (Benson Ave.)**
 Westward movements proceeding at 10 miles per hour or less within 1800 feet of crossing and until crossing occupied ----- 10 10

5 PUBLIC CROSSINGS AT GRADE

5.1 **Mileage 34.8 (Francois Drive)** — Automatically protected. Crossing Circuit sign to indicate location of restart circuit located 350 feet west of crossing. To avoid unnecessary operation of crossing signals, equipment must be left west of this sign during switching operations and eastward main track movements requiring to stop at Burns Lake should stop west of this sign.

5.2 **Mileage 85.2 (Benson Ave.)**—Automatically protected. Equipped with push button. Crossing circuit sign 300 feet east of crossing marks location of restart circuit after protection has timed out.

Westward main track movements standing just east of crossing to fulfil meet or wait orders will use push button cutout to de-activate crossing protection. Crossing must then not be occupied until protection has been in operation for at least 20 seconds.

6 SPURS AND OTHER TRACKS

6.1	Mileage	Capacity in Feet	Points Face
Tibbetts (Babine Forest Prods.)	22.0	6080	E W
J. T. Nicholson	34.2	500	E
Cigas Products Ltd.	36.5	770	W
Decker Lake Forest Products Ltd.	40.5	320	W
Decker Lake Forest Products Ltd.	45.5	2490	E W
Granisle Copper Ltd.	67.7	2070	E W
Noranda Mines	68.6	1220	E W
Railway Industrial Lead	85.4	1490	W
Northwood Pulp Ltd.	88.3	12920	W
Pacific Inland Resources Ltd.	115.8	1130	E W